

IPC-7526A

2022 - March

Stencil and Misprinted Board Cleaning Handbook

Supersedes IPC-7526
February 2007

An international standard developed by IPC



BUILD ELECTRONICS BETTER

The Principles of Standardization

In May 1995 the IPC's Technical Activities Executive Committee (TAEC) adopted Principles of Standardization as a guiding principle of IPC's standardization efforts.

Standards Should:

- Show relationship to Design for Manufacturability (DFM) and Design for the Environment (DFE)
- Minimize time to market
- Contain simple (simplified) language
- Just include spec information
- Focus on end product performance
- Include a feedback system on use and problems for future improvement

Standards Should Not:

- Inhibit innovation
- Increase time-to-market
- Keep people out
- Increase cycle time
- Tell you how to make something
- Contain anything that cannot be defended with data

Notice

IPC Standards and Publications are designed to serve the public interest through eliminating misunderstandings between manufacturers and purchasers, facilitating interchangeability and improvement of products, and assisting the purchaser in selecting and obtaining with minimum delay the proper product for his particular need. Existence of such Standards and Publications shall not in any respect preclude any member or nonmember of IPC from manufacturing or selling products not conforming to such Standards and Publication, nor shall the existence of such Standards and Publications preclude their voluntary use by those other than IPC members, whether the standard is to be used either domestically or internationally.

Recommended Standards and Publications are adopted by IPC without regard to whether their adoption may involve patents on articles, materials, or processes. By such action, IPC does not assume any liability to any patent owner, nor do they assume any obligation whatever to parties adopting the Recommended Standard or Publication. Users are also wholly responsible for protecting themselves against all claims of liabilities for patent infringement.

IPC Position Statement on Specification Revision Change

It is the position of IPC's Technical Activities Executive Committee that the use and implementation of IPC publications is voluntary and is part of a relationship entered into by customer and supplier. When an IPC publication is updated and a new revision is published, it is the opinion of the TAEC that the use of the new revision as part of an existing relationship is not automatic unless required by the contract. The TAEC recommends the use of the latest revision. Adopted October 6, 1998

Why is there a charge for this document?

Your purchase of this document contributes to the ongoing development of new and updated industry standards and publications. Standards allow manufacturers, customers, and suppliers to understand one another better. Standards allow manufacturers greater efficiencies when they can set up their processes to meet industry standards, allowing them to offer their customers lower costs.

IPC spends hundreds of thousands of dollars annually to support IPC's volunteers in the standards and publications development process. There are many rounds of drafts sent out for review and the committees spend hundreds of hours in review and development. IPC's staff attends and participates in committee activities, typesets and circulates document drafts, and follows all necessary procedures to qualify for ANSI approval.

IPC's membership dues have been kept low to allow as many companies as possible to participate. Therefore, the standards and publications revenue is necessary to complement dues revenue. The price schedule offers a 50% discount to IPC members. If your company buys IPC standards and publications, why not take advantage of this and the many other benefits of IPC membership as well? For more information on membership in IPC, please visit www.ipc.org or call 847/597-2872.

Thank you for your continued support.



IPC-7526A

Stencil and Misprinted Board Cleaning Handbook

Developed by the Stencil Cleaning Task Group (5-31g) of the
Cleaning and Coating Committee (5-30) of IPC

Supersedes:
IPC-7526 - February 2007

Users of this publication are encouraged to participate in the development
of future revisions.

Contact:

IPC
3000 Lakeside Drive, Suite 309S
Bannockburn, Illinois
60015-1219
Tel 847 615.7100
Fax 847 615.7105

This Page Intentionally Left Blank

Acknowledgment

Any document involving a complex technology draws material from a vast number of sources across many continents. While the principal members of the Stencil Cleaning Task Group (5-31g) of the Cleaning and Coating Committee (5-30) are shown below, it is not possible to include all of those who assisted in the evolution of this standard. To each of them, the members of the IPC extend their gratitude.

Cleaning and Coating Committee (5-30)

Chair:
Jason Keeping
Celestica

Vice Chair:
Graham Naisbitt
Gen3 Systems Limited

Cleaning and Alternatives Subcommittee

Chair:
Umut Tosun
Zestron Americas

Vice-Chair:
Michael Konrad
Aqueous Technologies Corporation

Stencil Cleaning Task Group (5-31g)

Chair:
Mike Bixenman
Kyzen Corporation

Vice Chair:
Greg Wade
Indium

Technical Liaisons of the IPC Board of Directors

Bob Neves
Microtek (Changzhou) Laboratories

Special Acknowledgment

Bob Willis, The SMART Group, for supplying many of the images utilized in the document.

Contributing 5-31g Committee Members

Constantino Gonzalez
ACME Training & Consulting

Jeff Schake
ASM Assembly Systems

Jason Keeping
Celestica International L P

Caroline Ehlinger
Collins Aerospace

Douglas Pauls
Collins Aerospace

Miguel Dominguez
Continental Temic SA de CV

Jose Servin Olivares
Continental Temic SA de CV

Beverley Christian
HDP User Group

Kyle Loomis
Kester

Mike Bixenman
Kyzen Corporation

David Lober
Kyzen Corporation

Robert Cochran
Mind Chasers Inc

Scott Homan
MPC Design Technologies

Linda Woody
LWC Consulting

Bill Vuono
Qorvo US Inc

Gaston Hidalgo
Toyota Motor North America

Ravi Parthasarathy
ZESTRON Americas

Umut Tosun
ZESTRON Americas

This Page Intentionally Left Blank

Table of Contents

1.0 SCOPE	1	3.12.5 Solder Paste Inconsistency	9
1.1 Statement of Scope	1	3.12.6 Deficient Solder Paste	10
1.2 Purpose	1	3.12.7 Excessive Solder Paste	10
1.2.1 Problem Statement	1	3.12.8 Defective Stencils	11
2.0 APPLICABLE DOCUMENTS	1	3.12.9 Poor Wetted Solder Joints	11
2.1 Reference Documents	1	3.12.10 Stencil Coplanarity	12
2.2 Joint Industry Standards	1	3.12.11 Inconsistent Component Pad Width	13
2.3 Surface Mount Technology Association (SMTA)	1	3.12.12 Alignment Accuracy	13
2.4 American Standards for Testing Materials	1	4.0 STENCIL PRINTING	14
2.5 Federal Laws and Standards	1	4.1 Introduction to Stencil Printing	14
2.6 Department of Defense	2	4.1.2 Surface Mount Trends	14
2.7 Occupational Safety and Health Administration	2	4.2 Factors Affecting the Cleanability of the Solder Paste	14
2.8 Environmental Protection Agency (EPA)	2	4.2.1 Solder Paste Flux Composition	15
2.9 Department of Transportation	2	4.2.2 Print Process	15
2.10 National Fire Protection Association (NFPA)	2	4.2.3 Stencil Type	16
2.11 Air Quality Management Standards (AQMD)	2	4.2.4 Aperture Ratio Calculation	16
3.0 STENCIL CLEANING PROCESS	2	4.2.5 Understencil Cleaning	17
3.1 Process Overview	2	5.0 STENCIL PRINTER CHALLENGES AS IT RELATES TO CLEANING	17
3.2 Stencils	3	5.1 Aperture Fill & Release	17
3.2.1 Chemical Etching	3	5.2 Gasket	17
3.2.2 Laser Cut Process	3	5.3 Area Ratio	18
3.2.3 Nickel Additive	3	5.4 Interspacing	19
3.2.4 Electroform, or E-form	3	5.5 Stencil Options	19
3.2.5 Stencil Material Compatibility	3	5.5.2 Application Specific Cleaning Challenges	20
3.3 Tools	4	5.5.3 On Printer Cleaning Mitigation Strategies	21
3.4 Pallets	4	6.0 UNDERSTENCIL WIPING	23
3.5 Misprint Circuit Board Cleaning	4	6.1 Understencil Wiping	23
3.6 Misprinted Solder Paste	4	6.2 Understencil Wipe Process	25
3.7 Single-sided Misprint Boards	4	6.2.1 Cleaning Steps	25
3.8 Double-sided Misprint Boards	4	6.2.2 Dry Wipe	27
3.9 Misprinted SMT Adhesives	5	6.3 Engineered Cleaning Solvents for Understencil Cleaning	27
3.10 Misprint Process Considerations	5	6.4 Wiping Sequences	29
3.11 Why Clean SMT Stencils?	6	6.4.1 Dry Wipe	29
3.12 Common Production Problems	6	6.4.2 IPA Wipe	29
3.12.1 Cleaning Stencil Underside	7	6.4.3 Engineered Solvent Wipe	29
3.12.2 Uncleaned Stencil Apertures	7	6.4.4 Engineered Solvent-Aqueous Wipe/Dry/Vac	30
3.12.3 Solder Paste Build up on Bottom Side of Stencil	8	6.5 Understencil Desirable Properties	30
3.12.4 Solder Paste Build-up on the Aperture Side Walls	8	6.6 Determining Wipe Frequency	30

7.0 ENVIRONMENTAL, HEALTH AND SAFETY (EHS) REQUIREMENTS	31	10.0 MISPRINT CLEANING	39
7.1 EHS Requirements	31	10.1 Misprint Cleaning Introduction	39
7.2 Employee Exposure to Stencil Cleaning Materials/Ingredients	31	10.2 Filtration Systems	41
7.3 Hazard Communication	31	10.3 Equipment Options	41
7.3.1 GHS Safety Data Sheet (SDS)	32	10.3.1 Inline Cleaning Equipment	41
7.3.2 GHS Hazard Classification	32	10.3.2 Batch Cleaning Equipment	42
7.3.3 GHS Container Labels	32		
7.4 Other Employee Exposure Issues	32	Figures	
7.4.1 Fire Safety Requirements	32	Figure 3-1 Typical Stencil Frame	3
7.4.2 Air Emissions / Permitting	32	Figure 3-2 Chemical Etch Stencil	3
7.4.3 Solid Waste Management	33	Figure 3-3 Chemical Aperture Walls	3
7.5 REACH	33	Figure 3-4 Laser Aperture	3
		Figure 3-5 Laser Aperture	4
8.0 STENCIL CLEANING AGENTS AND METHODS OFF THE PRINTER	33	Figure 3-6 Nickel Additive	4
8.1 Stencil Cleaning Agents and Methods	33	Figure 3-7 Nickel Additive	4
8.2 Matching the Cleaning Agent to Process	34	Figure 3-8 Electroform Aperture	4
8.2.1 Manual Stencil Cleaning using Pre-Saturated Wipes	34	Figure 3-9a Cleaning a Stencil Using a Brush	6
8.2.2 Solvent Cleaning with No Water Rinse	34	Figure 3-9b Damaging of Small Features After Brushing	6
8.2.3 Solvent / Water composition with No Water Rinse	34	Figure 3-10 Cleaning Stencil Underside	7
8.2.4 Aqueous Engineered Compositions with a Water Rinse	34	Figure 3-11a Uncleaned Stencil Aperture	7
8.2.5 Low VOC Aqueous Engineered Compositions for Ultrasonic Stencil Cleaning Machines	35	Figure 3-11b Uncleaned Stencil Aperture	7
8.2.6 Low VOC Aqueous Engineered Compositions for Spray-in-Air Cleaning Machines	35	Figure 3-12a Excess Solder Paste	8
8.2.7 Aqueous Engineered Compositions	35	Figure 3-12b Solder Paste Bridging	8
		Figure 3-13a Lack of Solder Paste	8
9.0 STENCIL CLEANING METHODS OFF THE PRINTER	36	Figure 3-13b Open Solder Joint	8
9.1 Stencil Cleaning Methods	36	Figure 3-14a Solder Paste Applied Inconsistent	9
9.2 Common Cleaning Methods	36	Figure 3-14b Inconsistent Solder Paste	9
9.2.1 Manual Wipe	36	Figure 3-14c Tombstoning of a Component	9
9.2.2 Ultrasonic Cleaning	36	Figure 3-14d Tombstoning of a Component	9
9.3.1 Manual	37	Figure 3-15a Inadequate Application of Solder Paste	10
9.3.2 Semi-Manual	37	Figure 3-15b Inadequate Solder Paste Deposition Creating Poor and Potentially Weak Solder Joints	10
9.3.3 Automated Wash/Rinse Methods	38	Figure 3-16a Excessive Application of Solder Paste	10
9.3.4 Pallet, Radiator, Squeegee Blades, Tooling	39	Figure 3-16b Excessive Application of Solder Paste	10
		Figure 3-17a Solder Balls Surrounding the SMT Pad Due to Excessive Solder Paste on Bottom Side of Stencil	10
		Figure 3-17b Solder Balls Surrounding the SMT Pad Due to Excessive Solder Paste on Bottom Side of Stencil	10
		Figure 3-18a Solder Spheres Migrating From Solder Pad	11
		Figure 3-18b Loose Solder Spheres (Balls)	11
		Figure 3-18c Loose Solder Spheres (Balls)	11

Figure 3-19a	Good Solder Joint Wetting	11	Figure 6-9a	Desirable Print	27
Figure 3-19b	Good Solder Joint Wetting	11	Figure 6-9b	Undesirable Print Showing Flux Bleed That Bridge Solder Prints.	27
Figure 3-19c	Bad Solder Joint Wetting	12	Figure 6-10a	Spray Type	28
Figure 3-19d	Bad Solder Joint Wetting	12	Figure 6-10b	Stencil Printer Orifices Designed to Wet Understencil Paper	28
Figure 3-20	Inadequate Stencil Coplanarity	12	Figure 6-11a	Flux Build-up and Solder Balls Observed in Stencil Apertures After First Print on Highly Dense Apertures	28
Figure 3-21	Inconsistent Solder Mask Thickness	13	Figure 6-11b	Flux Build-up and Solder Balls Observed in Stencil Apertures After First Print on Highly Dense Apertures	28
Figure 3-22	Component Pad Width	13	Figure 6-12a	Flux Build-up on Stencil Bottom Side After Three Prints	28
Figure 3-23	Alignment Accuracy.	13	Figure 6-12b	Flux Build-up on Stencil Bottom Side After Three Prints	28
Figure 4-1a	Ferrite Bead	14	Figure 6-13	Flux Streaks Following Dry Wipe	29
Figure 4-1b	Chip Resistor	14	Figure 6-15	IPA/Dry/Vac Wipe Example.	29
Figure 4-1c	BGA Bottom 368 Solder Balls.	14	Figure 6-16	Engineered Solvent Wipe/Dry/Vac.	30
Figure 4-2a	Ferrite Beads in the tip of a 25 Gauge Needle.	15	Figure 6-17	Solvent-Water Azeotrope Wetness on Stencil Bottom	30
Figure 4-2b	BGA 0.400 mm Pitch.	15	Figure 9-1	Manual Wipe Method.	36
Figure 4-2c	BGA 0.300 mm Pitch.	15	Figure 9-2	Ultrasonic Cleaning	36
Figure 4-3	Incompatible Cleaning Solvent and Solder Paste	15	Figure 9-3	Spray-in-Air Cleaning	37
Figure 4-4a	Stencil Printing Cycle Time	15	Figure 10-1a	Solder Balls Wedged into No Solder Mask Defined Channels and Via Holes	40
Figure 4-4b	Stencil Cleaning/Wipe Frequency	15	Figure 10-1b	Solder Balls Wedged into No Solder Mask Defined Channels and Via Holes	40
Figure 4-5	Interaction Plot for Boards/Second	16	Figure 10-2	Board printed with wet solder paste.	40
Figure 4-6	Examples of an Acceptable Print	16	Figure 10-3	Reflowed Board	41
Figure 5-1	Illustration of the Stencil Aperture Gasket – Highlighting (red circles) the Gasketing Challenges for a NSMD vs. SMD Pad.	18	Tables		
Figure 5-2	Area Ratio Impacts Transfer Efficiency.	18	Table 3-1	Lists Process Recommendations when Cleaning Different Types of Contaminants from Misprinted Boards.	5
Figure 6-1	Image of the Stencil Printing Process.	23	Table 4-1	Stencil Aperture Size and Area Ratios Stencil Thickness	14
Figure 6-2a	Desirable - Smooth and Clean Aperture Wall	24	Table 7-1	Permissible Exposure Limits (PELs)	31
Figure 6-2b	Undesirable - Irregular and Uncleaned Aperture Wall	24	Table 7-2	Ratings for Flammable Liquids	32
Figure 6-3	Understencil Wipe Process.	25	Table 8-1	Stencil Cleaning Agents and Processing Methods	35
Figure 6-4	Excessive Solder Paste on Paper Can Indicate Process Related Issues	26			
Figure 6-5	Image of an Understencil Wipe Design Within the Stencil Printing Machine	26			
Figure 6-6	During the Wet Wipe, Solvent is Wicked Through Small Orifices to Wet an Area of the Wiper Roll.	26			
Figure 6-7	Vacuum System Designed to Extract Trace Solder Balls and Chemical Residues from the Bottom Side of the Stencil.	27			
Figure 6-8	Flux Smear Across the Bottom Side of the Stencil After a Dry Wiping Sequence (UV Tracer in Flux Illuminated by Back Light).	27			

This Page Intentionally Left Blank

Stencil and Misprinted Board Cleaning Handbook

1.0 SCOPE

1.1 Statement of Scope This handbook addresses understencil cleanliness during stencil printing, removal of solder paste from stencils following the cleaning process and misprint PCB board cleaning considerations.

1.2 Purpose The goal in stencil printing is to place an exact amount of material in a precise location on the PCB. The print medium might be solder paste, adhesive/glue, flux, or thick film materials. The squeegee speed or pressure can affect the quality of the material deposition, the stencil is the primary control mechanism for material deposition. The purpose of this handbook is to provide the assembler best practice guidelines for understencil cleanliness during the stencil printing process, and stencil cleaning once the stencil is removed from the stencil printer. The document also addresses best practices for cleaning a PCB that was misprinted.

1.2.1 Problem Statement: The stencil and PCB must be well aligned and in very tight contact (gasketing) to achieve an acceptable print. The problem is that poor contact between the stencil and the board can cause poor quality prints resulting in soldering defects. A common root cause of gasketing issues is solder paste on the stencil's contact side. The cleanliness of the stencil is critical to the success of the stencil printing process. Insufficient solder is the primary cause of defects originating from the stencil printing process; therefore, stencil cleanliness is an essential process step for delivering the proper amount of solder paste to the PCB pads.

2.0 APPLICABLE DOCUMENTS

The following documents are provided as possible sources of additional information.

2.1 Reference Documents

IPC-7525 Stencil Design Guidelines

IPC-A-610 Acceptability of Electronic Assemblies

IPC-7093 Bottom Terminated Components

IPC-CH-65 Guidelines for Cleaning of Printed Boards and Assemblies

IPC-SC-60 Post Solder Solvent Cleaning Handbook

IPC-SA-61 Post Solder Semi-Aqueous Cleaning Handbook

IPC-AC-62 Post Solder Aqueous Cleaning Handbook

IPC-CA-82 General Requirements for Thermally Conductive Adhesives

IPC-3406 Guidelines for Electrically Conductive Surface

IPC-3408 General Requirements for Anisotropically Conductive Adhesive Films

2.2 Joint Industry Standards

J-STD-001 Requirements for Soldered Electrical and Electronic Assemblies

J-STD-005 Requirements for Soldering Pastes

2.3 Surface Mount Technology Association (SMTA)

Stencil Printing Fundamentals Stencil Printing 101

2.4 American Standards for Testing Materials

ASTM Standards & Publications can be found at <https://www.astm.org/Standard/standards-and-publications.html>

2.5 Federal Laws and Standards

CAA Clean Air Act

CWA Clean Water Act

CERCLA Comprehensive Environmental Response, Compensation and Liability Act

RCRA Resource Conservation and Recovery Act

SARA Superfund Amendment and Reauthorization Act